



BT Pathway User Feature Codes

The following are the normal feature codes available to all users.

The **N** where shown should be replaced by the appropriate internal or external number (trunk access digit, i.e. 9 is required for external numbers). For example, with **152N** replace **N** with the extension number to which you wish to forward calls to.

The **X** where shown should be replaced by the digits required as explained in the feature column.

Where **@** is shown, this indicates the call should be placed on hold first, standard telephones should use the R (Recall) key, system keyphones should access the feature directly by picking the option using the scroll key under the display or by pressing a programmed-key.

Feature Code	Feature	Feature Code	Feature
2X or 3X	Internal Call (Extensions 20-37)	47	PA Announcement
0	Operator	45	PA Answer
67	Call Pickup (External Call)	46 HHMM	Reminder Call (set time in 24-hour format)
68	Call Pickup (Own Group)	48	Room Monitor
@ 40	Call Park	@ 5	Ringback
150	Do Not Disturb - Set/Cancel	65	General Call
151N	Call Forward Immediate - Set	5X	Direct Trunk Select (Lines 1-8 with 51-58)
151	Call Forward Immediate - Cancel	8X	Line Groups (81-83)
152N	Call Forward when Busy - Set	42 123 XXX	Change Extension PIN (Old PIN, New PIN)
152	Call Forward when Busy - Cancel	41 XXX	Lock/Unlock Extension (41 + PIN)
153N	Call Forward on No Answer - Set	@ 66	Tone Protect (Disable Call Waiting per call)
153	Call Forward on No Answer - Cancel	86	Open Door (@ 86 if on a call)
154N [pin]	Follow Me – Set (Dial own Extn number)	64	CLI Restrict (per call)
154	Follow Me – Cancel	38	Voicemail Target (for Call Forwarding)
157	Reset Extension	88	Voice Mailbox Access
40	Retrieve Parked Call	62 X N	Add Personal Speedial (index 0-9 + tel no')
60	Last Number Redial	61 X	Dial Personal Speedial (index 0-9)
43N	Page/Voice Call (one Systemphone)	7 XXX	Dial System Speedial (index 001-200)
44	Page (all Systemphones)		